



● Input adapters


- Input adapter for strain-gage transducers UI-10A (TEDS compatible) (With NDIS connectors)




- Input adapter for strain gages UI-11A (TEDS compatible)




- Input adapter for strain gage with operating lever UI-15A




- One-touch type input adapter for strain gages UI-16B



- Voltage input adapter UI-30A



- One-touch type input adapter UI-55A (CE compatible)



Connection cable N-97

Use when connecting a transducer to the UI-11A, UI-15A, or UI-16B connector plug.



Simplified Configuration of the PCD-400A and PCD-430A

